


GUIDE TO CHANGING THE DURAPEN


duraSign Pad Brilliance



GUIDE TO CHANGING THE PEN


StepOver provides you with a replacement duraPen and cord.

Replacing the pen:




1. The first step is to remove the old pen and the cord tied to the pad. This is done by placing the signature pad with the screen facing down, pulling up the loop slightly and pushing the pen through the loop. Threading it through the loop separates the cord and duraPen from the signature pad.

If you would like to continue using your old cord, go to step 2; otherwise, jump to step 4.



2. You now need to separate the old cord from the duraPen by pulling the cord through the loop at the end of the pen. The old duraPen and cord are now apart.


Repeat this step to separate your new duraPen from its cord.



3. Now thread one end of the string right through the loop at the end of your new duraPen. Open up the loop at that end of the string and thread the other end of the string through it. The string is now tied to the new pen.



GUIDE TO CHANGING THE PEN



4. Now push the free end of the cord right through the opening on the underside of your signature pad, so that you can pull the pen through the loop.

Your new duraPen is now tied to the signature pad and ready for use!